

MOTHER-32 7 DFAM

7 patches

møog


Moog House of Electronicus

An electronic pop-up and synth guided exploration of the power of sound. The Moog House Of Electronicus was open to the public daily from January 24 - 30 in Chinatown, LA. Visitors had the opportunity to get hands on with Moog synths and explore the deeper dimensions of sonic experience through interactive sculptural synthesis installations, an immersive audio visualization system, and daily synthesizer workshops led by synthesist Bana Haffar.

Learn More About The Moog House Of Electronicus

HOW TO PLAY THE KEYBOARD & CREATE A SEQUENCE ON MOTHER-32


PLAY THE KEYBOARD



HOW TO TEMPO SYNC THE MOTHER-32 AND DFAM

 1

MOTHER-32



(KB)

(STEP)

To Sync a DFAM to a Mother-32,

simply patch from the ASSIGN output jack on the Mother-32 Patchbay into the ADV/CLOCK input on the DFAM.

DFAM



Press **RUN/STOP** on your DFAM. This will ensure that it is ready to play when it begins receiving a Clock signal from the Mother-32.

CREATE A SEQUENCE


MOTHER-32



Press **RUN/STOP** on Mother-32. Both units should now be playing in sync.

Baroque As A Joke

MATCH ALL KNOBS, SWITCHES & PATCH LOCATIONS TO THE GRAPHICS BELOW.




NOTES:

This is a 3 Oscillator Synth. DFAM does not run but rather is triggered by Mother-32. Step 8 velocity must be turned up on the DFAM as marked. Program a sequence on the Mother-32.

DFAM

Deep Bounce

MATCH ALL KNOBS, SWITCHES & PATCH LOCATIONS TO THE GRAPHICS BELOW.




NOTES:

Program a sequence on the Mother-32. Set the **VCO2 Frequency** knob on DFAM to your desired pitch with Mother-32.

Lo-Fi Low End

MATCH ALL KNOBS, SWITCHES & PATCH LOCATIONS TO THE GRAPHICS BELOW.



NOTES:

Program a sequence on the Mother-32.

Play with VCA Decay on DFAM for longer and shorter release times.

Try switching Mother-32's VCF Mod Source from EG to LFO for light tremolo.

Play with DFAM's Velocity knobs for different rhythmic accents.

Raise the DFAM's Noise/Ext Level knob to 9 o'clock for added fun.



MATCH ALL KNOBS, SWITCHES & PATCH LOCATIONS TO THE GRAPHICS BELOW.





NOTES:


Mother-32 is set to drone.

Press keys 1, 2, or 3 on Mother-32 to add some darkness.

DFAM

ONE Faux ONE

MATCH ALL KNOBS, SWITCHES & PATCH LOCATIONS TO THE GRAPHICS BELOW.




NOTES:

Patch **LFO TRI** output on Mother-32 to **VCF DECAY** input on DFAM to vary kick decay length. Play with DFAM's **Velocity** knobs to change up the rhythm.

Turn the **Resonance** knob on the DFAM up all the way to create an electro kick.

3 Squares & A Sine

MATCH ALL KNOBS, SWITCHES & PATCH LOCATIONS TO THE GRAPHICS BELOW.




NOTES:

VCO 1 & VCO 2 on DFAM can be adjusted to taste. Try matching DFAM's VCOs with the frequency of the Mother-32.

DFAM


Sine Up For Noise

MATCH ALL KNOBS, SWITCHES & PATCH LOCATIONS TO THE GRAPHICS BELOW.



NOTES:

Program a sequence on the Mother-32. Set the **Mix** knob on Mother-32 to VCO and play with the **Cutoff** knob for some zaniness. Music is the key to all science and art – the link between metaphysics and physics through which the universal laws and their many applications can be understood.



Moog Music Is An Employee-Owned Company Based In Asheville, NC